

FORD

INSTRUCTIONS

MUSTANG, FAIRLANE, COMET

Rear Sway Bar Kit

control freak
suspensions[™]

www.FreakRide.com

ADJUSTABLE REAR SWAY BAR KIT

1965-71 MUSTANG

1966-67 FAIRLANE

1966-67 COMET



Tech Line: 407-696-2772

control freak
suspensions™

www.FreakRide.com



Installation Instructions

Adjustable Rear Sway Bar Kit
Part # ACC-2820

Sub-Frame System Contents

- ¾” Thick Solid Sway Bar in Hammertone Finish
- Two (2) Assembled Drop Tubes With Bushings and/or Rod Ends
- Two Sway Bar Black Steel B-Brackets with ¾” Black Polyurethane Bushings, differential brackets and U-Bolts.
- Two (2) ¾” Steel Sleeves
- New Hardware & Instructions

Thank you for purchasing a world-class Control Freak Suspensions® Mustang, Fairlane and Comet rear adjustable sway bar kit. We believe this system is the best available at any price. As with any aftermarket performance product, this system is recommended for off road use only. This system is typically subjected to uses that exceed its mechanical limits, so there is no warranty, expressed or implied. Blue Moon Services LLC and its Control Freak Suspensions brand cannot control how this product is installed or used. By purchasing this product you are assuming all risks associated with its installation and use and agree to possess appropriate skills for its installation and use. Blue Moon Services LLC and its Control Freak Suspensions brand, our vendors and suppliers will not be held responsible, liable or accountable for any injury, damage, loss, penalties or fines that occur, directly or indirectly, from the installation and use of this product..

Please note that while installation is relatively easy for those with moderate experience, novices should employ a professional for installation. Fit is guaranteed on vehicles that are unmolested...that is cars that have not suffered any chassis or significant sub-frame damage. Such damage can bend or alter the unitized body or chassis, making installation more difficult and may require chassis adjustment.

Read all of the instructions before starting installation.

IMPORTANT NOTES:

1. Installation of the rear adjustable sway bar kit is easy but drilling is required.
2. Use caution in jacking and stabilizing the vehicle. A lift is highly recommended.

What Else Do I Need?

- Drill with sharp ¾” and 7/16” bits
- Everything else you need is included in the kit

Installation

- Now is the perfect time to clean up the vehicle underside of debris, oil or other unsightly elements.
- Put the car securely on large jack stands or on a lift. A lift is preferred for ease of installation and safety. Do not compromise safety for expedience. Remove the rear wheels.

INSTALLATION

1. Attach the enclosed black spring perch brackets to the differential tube with the supplied U-bolts.
2. Lubricate the center hole on each of the poly bushings with the supplied lubrication.
3. Slide the sway bar bushings onto the sway bar. Now position the sway bar to the bushing brackets and onto the end of the U-bolts.



4. Attach the sway bar ends to the rod ends on the supplied drop tubes. Use the middle hole on the sway bar to attach.
5. With the sway bar forward legs parallel to the lower trailing arms, Swing the drop tubes up so they are perpendicular to the sway bar forward legs. Mark the center point on the inside of the chassis rails.



6. With the aid of a sharp 7/16" drill bit, drill all the way through the chassis rail.
7. With the aid of a sharp 3/4" drill bit, **enlarge the inside rail 7/16" hole to 3/4"**. To make this easier, you may wish to use a sharp step bit. Do this to both sides.
8. You can now slide the provided 3/4" steel tubes into the chassis rails from the **INSIDE** of the rail. Lubricate the center of the bushings with the supplied lubricant and slide the bushing ends over the steel tubes. From the outside of the chassis slide the long 7/16" bolt through a washer and the chassis rail, and then through the bushing ends on the inside of the rail. Place another supplied washer and Nylock nut onto the bolt and tighten. Repeat on the other side.
9. Now torque all the bolts and you are done with the installation of the sway bar.

Congratulations...you are finished!!

Tech Line: 407-696-2772



PAYMENT

We accept VISA, MasterCard, Discover, American Express, PayPal, Wire Transfer, Certified Check and Money Order.

DELIVERY

Orders for small systems and components usually ship within two (2) weeks. IFS Systems typically ship within six (6) weeks, depending on options. Air and other expedited options are available upon request and are subject to special handling charges.

RETURNS

Product returns & exchanges must be called in for authorization prior to return and shipped freight pre-paid with a copy of the original invoice. Shipments without proper paperwork will be refused. Returns are subject to a 15% restocking charge or Fifteen Dollar (\$15.00) minimum. Freight charges are non-refundable. All returns or Exchanges must be made within thirty (30) days of purchase date from Control Freak Suspensions. Product that has been installed, cut, scratched or painted cannot be returned.

CUSTOM PRODUCTS

Custom production items require full payment with the order and are non-returnable.

ORDERING

Orders can be placed on our website (www.FreakRide.com) or by calling 407-696-2772. You may also Email to: sales@FreakRide.com

WARRANTY DISCLAIMER

Purchaser understands and recognizes that racing parts equipment and services provided by, manufactured and/or sold by Blue Moon Services LLC d/b/a Control Freak Suspensions are subject to varied conditions due to the manner in which they are installed and used. Purchaser further recognizes and agrees that suitability of any part sold or manufactured by Blue Moon Services LLC d/b/a Control Freak Suspensions for a particular application is the purchaser's decision and that the purchaser is not relying on the skill or judgment of Blue Moon Services LLC d/b/a Control Freak Suspensions regarding suitability of any product or service. Blue Moon Services LLC d/b/a Control Freak Suspensions makes no warranties whatsoever, expressed or implied, oral or written to purchasers. There is no warranty of merchantability made to purchasers with regard to off road, racing and racing equipment.

Liability is limited to repair or replacement of defective parts to original purchaser. Blue Moon Services LLC, d/b/a Control Freak Suspensions is not liable for any consequential damages, expenses or injury arising from the use, misuse, or improper installation of any product manufactured or sold by Blue Moon Services LLC d/b/a Control Freak Suspensions. Blue Moon Services LLC d/b/a Control Freak Suspensions is not responsible for any labor or shipping costs associated with any warranty claim. Blue Moon Services LLC d/b/a Control Freak Suspensions reserves the right to make changes in design or add to or improve its product without incurring any obligation to install the same on any products previously manufactured. This warranty shall not apply to any product which has been repaired or altered in any way so as in our judgment to affect its performance; nor which has been subject to misuse, abuse, negligence, racing or any other occurrence beyond the control of Blue Moon Services LLC d/b/a Control Freak Suspensions. The information in this catalog is deemed accurate to the best of our knowledge and belief. However, Blue Moon Services LLC d/b/a Control Freak Suspensions cannot assume responsibility for possible error.

FORD

INSTRUCTIONS

MUSTANG, FAIRLANE, COMET

Rear Sway Bar Kit

control freak
suspensions[™]

www.FreakRide.com

Control Freak Suspensions
2920 West Airport Blvd., Suite 110
Sanford, FL 32771
407-696-2772
www.FreakRide.com

